

COMPOSITE DECKING CLEANER

For cleaning and reviving composite decking

- Ready for use
- Fast and effective
- Removes dirt, moss, grease, stains, algae and mildew
- Can also be used on timber decking
- Suitable for pressure washers

Rustins Composite Decking Cleaner is based on a blend of special cleaning agents to remove dirt, algae, mildew and grease from old and new exterior composite decking.

Preparation

All loose dirt, grease, mildew and mould should be removed using a stiff garden broom or pressure washer.

Application

Shake well before use. Do not dilute. Apply Rustins Composite Decking Cleaner with a watering can, sprayer or a brush. After 10 minutes, the surface should be scrubbed with a stiff garden broom. After a further 30 minutes, rinse the surface with clean water using a stiff broom, garden hose or pressure washer. Repeat the process as necessary until the deck is clean.

Drying time

Allow the surface to dry thoroughly before applying Rustins Quick Dry Decking Oil.

Coverage

The contents of this container will clean 45-50 square metres.

Cleaning

All equipment should be cleaned with plenty of water.

Maintenance

Repeat the application of Composite Decking Cleaner when necessary.

Health & Safety

Keep out of reach of children.

Do not get in eyes, on skin, or on clothing.

Wear protective gloves/protective clothing/eye protection/face protection.

IF SWALLOWED: Call a POISON CENTRE or doctor if you feel unwell.

IF ON SKIN: Wash with plenty of soap and water

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Please refer to Product Data Sheet for full information at www.rustins.co.uk

For information on Rustins' products visit our website at www.rustins.co.uk or contact us at Rustins Ltd, Waterloo Road, London, NW2 7TX UK rustins@rustins.co.uk

Tel: +44 (0)20 8450 4666



4 Litree